

COLORWOOD — LATVIA —

WOODEN BOXES FOR HOME AND BUSINESS


FRUIT BOX MEDIUM



ASSEMBLY MANUAL FOR "DIY HOBBY" WOODEN BOX


SET VISUALIZATION

1.



The set contains: planks, nails, sandpaper. To assembly cetrain box model you need a hammer, a pencil and pliers.

3.



It is possible that staples may get stuck in the plank. In that case you need to extract them by using pliers.

SIDES AND BOTTOM

5.



Nail the planks together, starting with the sides. Carefully set the same distance between the boards. For each plank use two nails.


7.



Lastly, nail the bottom of the box to the the sides. Carefully set the same distance between the boards. For each plank use two nails.

BOX OPENING

2.



Our product is nature friendly. Instead of harmful glue we use staples. It fastens package to the first plank.

1. Open a cardboard lock.
2. Tear off stapled side of package.

4.



Sort the planks by groups. Longest planks - box bottom (A). Shortest planks - box sides (B).

6.




Go on to the opposite side. Carefully set the same distance between the boards. For each plank use two nails.

FINISHED BOX



Smoothen the sharp edges with the provided sand paper. The box is finished!

! ADVICE



If the nail goes in at an angle, it can be fixed easily.

1. Rip out the plank with the nail.
2. Bend the nail at the correct angle.
3. Nail it back in.

! ADVICE



You can use screws to make the box even stronger. **Screws are not included!**